

Testing concrete —

Part 111: Method of normal curing of test specimens (20 °C method)